

# Wind deflectors for side windows

## FITTING INSTRUCTIONS

### » Step 1: Clean up the gluing surface



Installation should be made with the side window wound down. First thing to do is to precisely clean (with mild solvent or window cleaner) the surface that the deflector will be attached to. Wait until the cleaning liquid evaporates.

### » Step 2: Remove adhesive tape backing



Next step is to remove the backing from the adhesive tape.

### » Step 3: Push the deflector into the seal



Push the deflector into the slot under the seal, beginning with the end of the deflector.

### » Step 4: ...and bend it slightly



Bend the deflector slightly in order to fit easily. Push the deflector into the slot and hold until it sticks properly.

### » Step 5: Tighten the deflector



Push the deflector into the slot and hold until it sticks properly.

### » Step 6: Leave the deflector overnight



Close the window and leave the deflector for the night to let it fit precisely.

### » Metal clips fitting instructions



Front door



Back door

The clips should go inside the window channel with the spike facing towards the inside. For the video instructions, please visit <http://www.heko.pl/index.php?opt=instr>

### Warning!

- » Improper installation of the wind deflector may cause its disconnection during travelling and be dangerous for the other traffic users.
  - » In models with electric window position sensor improper installation may cause full closure of the window and the closing mechanism damage.
  - » If you aren't sure how to install our wind deflector – contact your mechanic.
- » Eternalcar doesn't take any responsibility for damage caused from improper installation.