


# ACUDA SPRINT PLUS





SILVER 50188  
BLACK 50189

WWW.AGURI.EU





I Istruzioni per il montaggio  
GB Fitting instructions  
F Instructions de montage  
D Montageanleitung  
E Instrucciones de montaje  
NL Montage-instructies  
DK Montering instruktion  
FIN Asennusohje  
S Monteringsanvisning  
RU Инструкция по установке  
PT Instruções de Montagem  
EST Paigaldusjuhend  
LAT Stiprināšanas instrukcija

LIT Pritvirtinimo instrukcijos  
PL Instrukcja montażu  
CZ Návod na montáž  
SK Návod na montáž  
SLONavodila za pritrjevanje  
HR Uputa za sastavljanje  
HU A felszerelés módja  
GR Οδηγίες συναρμολόγησης  
UA Інструкція з монтажу  
BY Інструкцыя па мантажы  
RO Instrucțiuni de montare  
TK Uydurma talimat  
N Monteringsveiledning




# OPTION I


## UNIVERSAL



### FRONT




### REAR




# OPTION II

ALUMINIUM




## FRONT


1.



2.




3.




## REAR


1.







2.



3.



SIZE 15



SIZE 9

